



KEY		
	SOURCE 4 26DEG	575W
	SOURCE 4 36DEG	575W
	6' FRESNELITE	750W
	BARNDOOR	
	6' ALTMAN FRES	500W
	GIOTTO WASH 400	400W
	GIOTTO SPOT 400	400W
	COLORWIZ ANALOG SCROLLER	
	ALTMAN 2 CELL SKY-CYC	300W
	BIRDIE WIDE FLOOD	50-75W
	PRACTICALS	
	FOCUS/PURPOSE COLOR	
	UNIT NUMBER	
	TEMPLATE	
	SHOW SPECIAL	
	CHANNEL	

HANG NOTES:

- THREE-FER BLUE WASH, CHANNELS 61&62. TWO-FER PINK WASH, CHANNELS 64&66. TWO LAV WASH, CHANNELS 63&65. TWO-FER HOUSE LIGHT CHANNEL 1 (TWO-FER AGAIN AT DIMMER, 4 INSTRUMENTS TOTAL) ALL OTHER INSTRUMENTS ARE SINGLED.
- PROVIDE NON-DIM POWER FOR MOVING LIGHTS: TWO-FER INSTRUMENTS ON EITHER SIDE AND RUN DOWN TO WALL OUTLETS BEHIND SEATS.
- PROVIDE NON-DIM POWER FOR SCROLLERS: TWO-FER AND THREE-FER AS NECESSARY AND RUN BACK TO OUTLET IN BOOTH.
- RUN DMX UNIVERSE 2 TO ANALOG SCROLLER CONTROL BOX IN BOTH AND THEN DAISY CHAIN THE 4 MOVING LIGHTS TO DMX. RUN DMX FROM LAST MOVER TO BACK WALL AND DROP DOWN FOR DECK SCROLLER OR HAZER CONTROL. TERMINATE THIS RUN! TWO-FER CONTROL CABLE AS NECESSARY.
- TEMPLATES AND COLOR TBA FROM STOCK
- INSTALL SAFETY CABLES ON ALL UNITS
- LABEL BOTH ENDS OF EVERY POWER AND CONTROL CABLE!!!
- FIXTURES WITH THE WINDOW GOBOS ARE TO BE HUNG 5 FT UNDER THE GRID. ONE WAY TO DO THIS IS HANG THEM WITH THREADED COMING OUT OF THE C-PLAMP DOWN TO THE FIXTURE.

THIS DOCUMENT REPRESENTS VISUAL DESIGN IDEAS ONLY. NO REPRESENTATION AS TO ELECTRICAL OR STRUCTURAL APPROPRIATENESS IS MADE. THE DESIGNER ASSUMES NO RESPONSIBILITY FOR INAPPROPRIATE INSTALLATION OR OPERATION OF THE EQUIPMENT REFERENCED ON OR BY THIS DOCUMENT. PLEASE FOLLOW ALL APPLICABLE STRUCTURAL, ELECTRICAL, FIRE AND SAFETY CODES WHEN INSTALLING AND/OR OPERATING THIS EQUIPMENT.